


Attention!
Do NOT use the "Fit To Paper" feature!
Make sure that "Page Scaling" says "None"!

The line below should be exactly 6 inches long (152.4 mm).



On first fit, Dance Paws® should feel tight. They will stretch to their final fit in four to six hours of wear.

We recommend professional fitting for comfort and performance. Shoe sizes are only a guideline.

<i>Dance Paws®</i>	<i>US women's shoe</i>
XXS	11 – 13 (children's)
XS	3 – 4½
S	5 – 6½
M	7 – 8
L	8½ – 9½
XL	10 – 11
XXL	11½ – 13

Place your foot as shown above. Measure the widest diameter of your foot, from the joint just below the base of the big toe to the joint below the little toe.

This chart accounts for the width of your foot but not the thickness. If you have thick feet and are more than halfway across a size column, consider one size larger. If you have a high instep and are less than halfway across a size column, consider one size smaller.

Call Dance Paws® tollfree 866.326.2829.